

# ROLLERSKI USER GUIDE



Please keep this user guide in a safe place.

Thank you for choosing Fischer rollerskis. The product portfolio has been developed together with cross country skiing experts especially for the sport of rollerskiing. You have thus made an excellent choice and we wish you a lot of pleasure with your rollerskis.

## NOTES ON SAFETY AND WARNINGS

- Rollerskiing is a complex activity which involves certain risks. Please note that the risks associated with rollerskiing can lead to serious or even fatal injuries.
- Rollerskis are designed exclusively for rollerskiing. All components (e.g. bindings) used in connection with the rollerski must be designed for this type of use. A professional retailer must be consulted to clarify this point.
- The mounting of bindings and rollerski settings or adjustments are to be carried out by authorised retailers. Any adjustments made by an unauthorised person are at your own risk and render the warranty void.
- Make sure that your rollerski equipment is working properly and that there are no defective or missing parts every time before use. Check that all screws are tight. If a repair is necessary, have your equipment repaired by an authorised retailer. Using a defective rollerski increases the risk of injury.
- Self-locking screws can become loose over time. If you completely undo a self-locking screw it must be replaced with a new one and adhesive must be properly applied. Any damage as a result of non-replaced screws is not covered by warranty.
- As a user of rollerskis you have to be aware of the risks involved in this sport.
- Make sure that your rollerskiing style and the tours and downhill you select are suitable for your level and respective rollerskiing skills.
- Observe all legal requirements which are in force.
- Do not use rollerskis if you do not feel physically fit, feel tired or are under the influence of alcohol, drugs or medication.

## USE

- When using the rollerskis for the first time, use them on level and dry asphalt so the protective coating of the rubber wheels can be removed. Distance: approx. 5 km.
- The rollerski models are designed for a maximum body weight of 100 kg (220 lbs). Any additional weight would mean that optimum performance is no longer guaranteed.
- We recommend you wear protective equipment (helmet, hand, knee and elbow protection) at all times when rollerskiing. If visibility is poor or the light is fading at dusk we likewise recommend reflectors on clothing and equipment (e.g. poles, boots, etc.).
- Rollerskis have no integrated brake! The use of rollerskis is exclusively at the user's risk!

## MAINTENANCE AND CARE

- Do not use any cleaners or solvents to clean your rollerskis! We also recommend that you do not use high-pressure cleaners. You can clean the rollerskis with warm water and a moist cloth. Dry them well afterwards.
- The ball bearings used are maintenance-free and do not require any special attention.
- Keep the rollerskis in a cool, dry and well aired place where they are protected against light.
- Mounting or replacing any parts can affect the performance of the rollerskis. Only original parts (wheels, bearings, screws, etc.) may be used. The mounting/assembly of such parts must be carried out by a specialist (authorised retailer).

## CLAIMS AND GUARANTEE

Fischer products are subject to stringent quality requirements. However, should any material or manufacturing defects occur, a claim may be submitted in accordance with the legally valid warranty. The claim can be settled only with proof of purchase (receipt) at the retailer where the rollerskis were purchased. No claims will be accepted for normal wear and tear or for damage resulting from improper or negligent use, care or storage.